## **Explanation of abbreviations**

A	= dimension A	LL	= left hand rotation
a <sub>e</sub>	<ul> <li>cutting thickness (radial)</li> </ul>		
a	<ul> <li>cutting depth (axial)</li> </ul>	М	= metric thread
А́ВМ	= dimension	MBM	<ul> <li>minimum order quantity</li> </ul>
APL	= panel raising length	MC	<ul> <li>multi-purpose steel, coated</li> </ul>
APT	= panel raising depth	MD	= thickness of knife
AL	= working length	min⁻¹	<ul> <li>revolutions per minute (RPM)</li> </ul>
AM	= number of knives	МК	= morse taper
AS	= anti sound (low noise design)	m min <sup>-1</sup>	= metres per minute
		m s <sup>-1</sup>	= metres per second
b	= overhang		
B	- width	n	– BPM
חחפ	- thickness of shoulder	n	– movimum pormiosible PDM
			= maximum permissible hrivi
BEZ		ND	
BH	= tipping neight	NH	= zero neight
BO	= bore diameter	NL	= cutting length
		NLA	= pinhole dimensions
CNC	= Computerized Numerical Control	NT	= grooving depth
d	= diameter	Р	= profile
D	<ul> <li>cutting circle diameter</li> </ul>	POS	<ul> <li>cutter position</li> </ul>
D0	= zero diameter	PT	= profile depth
DA	<ul> <li>outside Diameter</li> </ul>	PG	= profile group
DB	<ul> <li>diameter of shoulder</li> </ul>		
DFC	<ul> <li>Dust Flow Control (optimised chip clearance)</li> </ul>	QAL	<ul> <li>cutting material quality</li> </ul>
DGL	= number of links		
DIK	= thickness	R	= radius
DKN	<ul> <li>double keyway</li> </ul>	RD	= right hand twist
DP	<ul> <li>nolvervstalline diamond</li> </ul>	RI	<ul> <li>right hand rotation</li> </ul>
ופח	- rotation	DD	- radius of outtor
		NF	
FAB	<ul> <li>width of rebate</li> </ul>	S	= shank dimension
FAT	= depth of rebate	SB	= cutting width
FAW	= bevel angle	SET	= set
FLD	= flange diameter	SLB	= slotting width
f	= tooth feed	SU	= slotting length
f	= effective tooth feed	SLT	= slotting depth
z eff		SP	
GEW/	- thread	ST ST	- Cobalt-basis cast allovs
GL	- total longth	01	- Cobait-basis cast alloys,
GL CC	- lotal length	070	e.g. Stellt
65	= Plunging edge	510	
		500	= cutting angle
Н	= height		
HC	<ul> <li>tungsten carbide, coated</li> </ul>	TD	<ul> <li>diameter of tool body</li> </ul>
HD	<ul> <li>wood thickness (thickness of workpiece)</li> </ul>	TDI	= thickness of tool
HL	<ul> <li>high-alloyed tool steel</li> </ul>	TG	= pitch
HS	<ul> <li>high-speed steel (HSS)</li> </ul>	ТК	<ul> <li>reference diameter</li> </ul>
HW	= tungsten carbide (TCT)		
ID	= ident number	UI	= cutting eages with irregular pitch
IV	= insulation glazing	V	= number of spurs
		V	<ul> <li>cutting speed</li> </ul>
KB7		°c V	<ul> <li>feed sneed</li> </ul>
KLH	- clamping beight		- nacking unit
	- clamping neight		- packing unit
		V2R	= aujustment range
r IN	= single keyway		
KNL	= combination pinhole consists of	WSS	= workpiece material
	2///42 2/9/46,35 2/10/60	7	number of tooth
		<u>ک</u>	
L	= length	ZA	= number of fingers
1	= clamping length	∠F	= tooth shape (cutting edge shape)
LD	= left hand twist	ZL	= finger length

Notes to the Lexicon concerning the diagrams and tables

The statements made in the diagrams and tables relate to specific conditions and represent parameters from tests subjected to defined conditions. Variations when using tools in individual case due to special application conditions may be possible. Our support team will provide you with detailed information.